

SSCS Weighted Frond Mat
Manual Filling of the Edge Weight 'tubes'

- 1) Lift the tube and insert a solid pipe / tube for ease of inserting the aggregate (either 8-10mm shingle or sand):



- 2) Using a suitable shovel or similar fill the tube with aggregate:





3) When the tube is adequately filled, seal the end using the attached string / tie wrap:



- When filled and tied the tubes can be attached to the Frond Mat ready for deployment.
- When all four (4) tubes are attached the SSC Weighted Mat should weigh approximately 700-800kg.